# **USERS MANUAL**

29.2V25A LiFePO4 Battery Charger



# INSTRUCTION:

Thank you for purchasing our product. Please read the entire instruction strictly to use this charger. It is an economic, high quality,100-240V AC balance charger.

Charging program consists of 3 steps: constant current, constant voltage and float charging. The chargers provide

protections against overload, over-voltage, over-heating, short circuit and reverse polarity connections.

#### SPECIFICATIONS:

	DC Output
Maximum DC output voltage	29.2 V
Maximum DC output current	25 A
Maximum DC output power	700 W
Nominal DC output current	25A @ 110 VAC, 25A @ 220 VAC
Battery type	12S LiFePO4 Battery
	AC Input
AC input voltage range	85-270 VAC
Nominal AC input voltage	100-240 VAC
Nominal AC input frequency	50 / 60 Hz
Maximum AC input current	8A
Nominal AC input current	6A
Power factor	>0.9
	Mechanical
Dimensions	18.2 x 10.5 x 6.5 cm (7.16 x 4.13 x 2.55")
Weight	4 lbs (1.8 kg)
Cooling	Active cooling with fan
	Environmental
Enclosure	IP65
Humidity	5% - 95%
Operating temperature	-20 $^\circ\!\mathrm{C}$ to 80 $^\circ\!\mathrm{C}$ (-10 $^\circ\!\mathrm{F}$ to 176 $^\circ\!\mathrm{F}$ ), Derated at >60 $^\circ\!\mathrm{C}$ (140 $^\circ\!\mathrm{F}$ )
Storage temperature	-40 °C to 85 °C (-40°F to 185°F)

### LED LIGHT STATUS:

LED	Charger Status
1. LED solid green.	The charger is ready to charge, or Charging is complete.
2. LED Green blinking.	The charger is charging.
3. Red light blinking quickly.	Input power failure.
4. LED Red and green blinking alternately.	The output is short-circuited or the positive and negative
	poles of the battery are reversed.
5. Red light blinks 2 times, interval 1 second, then 2 times.	Charger temperature overheating alarm.
6. Red light blinks 3 times, interval 1 second, then 3 times.	Output over current alarm.
7. Red light blinks 4 times, interval 1 second, then 4 times.	Output over-voltage alarm.

If there is a problem with the charger, the fan will stop rotating and the LED indicator will blink red light to give an error

warning. Please disconnect the charger from the wall socket.

## WARNING AND SAFETY NOTES:

Ensure the battery system has the properly rated voltage, amp hours and type for this charger.

Never leave the charger unattended when it is connected to its power supply.

The allowable AC input voltage is 100-240V AC. Never connect it to any other voltage.

Never place the charger and batteries connected to it on any form of flammable surface. Never operate the charger in the

vicinity of inflammable material or gas.

Ensure that there is an unrestricted airflow to and from the charger's cooling slots. Never place the charger on a carpet or similar surface.

Never operate this charger if it has received any physical damage, been dropped, or received a sharp blow.

Do not disconnect the DC charging cord while charger is operating. This can cause arcing and/or explosion.

Never charge a frozen or non-rechargeable battery as they may explode, causing injury, death, property damage, and/or fire.

To reduce risk of fire, do not use it near flammable materials or vapors. Always use the charger on a non-combustible surface

(Metal,brick,concrete,etc)

Take great care to maintain correct battery polarity to avoid shot-circuit. There is information on charger to show wire color and polarity.

Read the battery manufacturer's instructions and adhere to them strictly.